



There are three screws on each prism cover plates, please loosen these three screws, then you can take off the cover plates from binoculars, and you can see the prisms as above picture, and there are three small focusing screws, you can use screw driver to adjust these focusing screws for collimation, and usually, our collimation standard for this binoculars on our collimation machine is:

Convergence (left and right): 80-120'

DipVergence (up and down): 30-40'