


FSQ-80FC Photo/Visual System Chart

▼Standard Accessories

- 6M Camera Angle Adjuster CAA-M [TKA23200N]
- 10 Coupling DT(FSQ-85ED) [TKP37001]
- 12 M48 Visual Adapter [KP00005]
- 14 Coupling(S) [TKP00103]
- 30A M72-M48 CMOS Adapter [TKP00200]
- 46 Eyepiece Adapter31.7 [TKP00101]
- 50A Aux Ring FB 52mm [TKA23250]



▼Optional Accessories

- 30B. M72-M54 CMOS Adapter [TKA00201]
- 30C. M72 WR adapter [TKA00202]
- 33. Camera mount DX-WR (EOS) [TKA01251]
Camera mount DX-WR (Nikon) [TKA01255]
- 34. DSLR
- 47. Eyepiece 31.7
- 48. Eyepiece 50.8
- 70S. Eyepiece holder 50.8 [TKP27110S]
- 74. Mirror Diagonal 50.8 [TKA00543]
- 75. 31.7 Adapter (DM) [TKA00111]
- 93. CMOS Camera (M48 P=0.75 female, Metal back=55mm)
- 94. CMOS Camera (M54 P=0.75 female, Metal back=55mm)

TAKAHASHI