

## New designed ASI1600 and ASI071 exchange desiccant note

Here is an instruction about how to exchange the desiccant tablets for our newest designed ASI1600 and ASI071 camera.



### Attention:

Only when dew problem happens on CMOS surface, you need to unscrew the air socket screw and insert the desiccant tube, and wait 24 hours for the sensor chamber become dry again.

### Step1

Take off the top cover from the Desiccant tube, put 2 pcs of new desiccant tablets into it and cover its back.



### Step2

Screw off the air socket screw from the camera body and attach the Desiccant tube.

